

THANK YOU FOR YOUR ORDER!

INSTALLATION INSTRUCTIONS



THE BEST TRAILER WIRING AND LIGHTING SYSTEM ON THE PLANET!
GET KRAKEN!

INSTALLATION INSTRUCTIONS -BOAT TRAILER



Trailer Preparation:

1. We recommend testing your vehicle beforehand to ensure your vehicle electrical is not an issue. All Kraken Wiring Harnesses and Lights are tested prior to shipping.
 2. Remove old wiring and lights
 3. Remove Kraken Harness from packaging, careful not to slice or cut the wiring when removing zip ties from harness
-

INSTALLATION INSTRUCTIONS -BOAT TRAILER



Installation:

1. Install tail lights using provided stainless steel hardware.
2. Beginning with Flat 4 vehicle connector, run the vehicle connector cable through the center beam of trailer frame or along the top or sides attached with supplied wire loom claps leaving approximately 20 inches past the tongue (Plug Flat 4 into tow vehicle to test length before final assembly) .
3. Refer to the ***Basic Kit Diagram*** for suggested routing of cable.
4. Connect all IP68 rated connectors securely using a small amount of die electric grease. Refer to the ***Basic Kit Diagram***.
5. Neatly secure the harness to your trailer frame. Install wire looms (clamps) approximately every 2 feet to secure wiring (coil wire into a service loop if there is extra length). To install wire looms, drill a 7/32" hole and use provided stainless steel hardware (use phillips head and 3/8" wrench to tighten)

*Note: As an alternative, zip ties may be used to **secure** wiring in place to trailer frame.*

*****Note: All connections in this Harness Kit must be used. Make sure all connections are plugged in with the cap tightened securely. Leaving a connector open to the elements will result in a blown fuse on the tow vehicle.*****



Again, thank you for your order!
Stickers provided would look great on your boat trailer!
Enjoy your time on the water worry free!



Instagram

@

krakenwiringllc

+ KRAKEN WIRING -

Basic Kit Diagram

